
Part 1 — What the function does

What it does. ReliaEn is installed once from its installer, and then works under a licence file. The licence file names your company, the edition you bought and the computer it is for. Until a licence is installed, ReliaEn is read-only: you can open and view projects, but no analysis runs. Help ▸ Licence… shows the licence, gives the computer's code to request one, and installs the file when it arrives - at once, with no restart.

Installing ReliaEn. ReliaEn 1.0.0 comes as one signed installer, ReliaEn-Setup-1.0.0.exe, for the x64 edition of Windows 10 (from its October 2018 update) or later. Double-click it and choose an installation for you only (no administrator rights, into %LOCALAPPDATA%\Programs\ReliaEn) or for all users (an administrator, into Program Files). The installer adds ReliaEn and Uninstall ReliaEn to the Start menu. It never installs an older version over a newer one. Uninstalling removes the program folder only: your projects, CMMS files and licence file stay.



The main window with no licence

- ① The licence segment at the right end of the status line: Unlicensed — read-only. One click on it opens Help ▸ Licence….

What ReliaEn shows	What it tells you
The licence segment	The state of the licence, in one sentence, at the right end of the status line
The licence dialog	The rows of the licence file (licensee, site, edition, features, seats, dates, licence id) and this computer's code
The report's last line	Whose licence made the report: Licensed to <licensee> · <licence id>

From which data. The licence file ReliaEn sends you (a file ending in .rlic) and this computer's code, which the licence is issued for.

When an engineer uses it. On a new computer, when the licence file arrives; at a renewal; when ReliaEn moves to another computer.

When not to use it.

Situation	Use instead
ReliaEn itself is to be updated to a newer version	Help ▸ Updates… (chapter 1.7)
The licence file is for another computer	Send this computer's code with Request licence by e-mail in the same dialog, for a transferred licence


---

Part 2 — The example's input data

Setting. A reliability engineer has installed ReliaEn on a new laptop. The licence file for it has arrived by e-mail.

Input	Value
Licence on the computer	none
The licence file	L-FULL.rlic — the test licence of ReliaEn's licence test suite (your file has your own name)
Licensee / site	ReliaEn Test Fixture Co., Ltd. / Fixture
Edition / seats	full / 1
Issued / expires	2026-09-15 / 2027-09-14
Licence id	RL-2026-0001
Date of the install	2026-09-15

The licence dialog before the install:




The licence dialog, no licence installed

- ① Status: Unlicensed — read-only; every other row shows —.
- ② This machine's code: RL-083A0F2D-AFD578B5-15C76AD2, with Copy beside it - the code a licence is requested for.
- ③ Install licence file...: installs a licence file.
- ④ Request licence by e-mail: writes the request, with this code, into the panel under the buttons and hands it to your e-mail program.
- ⑤ Close: closes the dialog.

Part 3 — How to use it, step by step


1. **Choose Help ▸ Licence…** in the menu bar, or click the licence segment of the status line. The dialog ReliaEn licence opens.



Step 1 — the menu path

- ① Help: the menu.
- ② Licence…: the entry to click.


2. ③ **Click Install licence file… and choose L-FULL.rlic** in the file chooser. ReliaEn reads the file and checks its signature before it copies anything; a file it cannot accept is refused with a sentence, and nothing changes.



Step 2 — the dialog's Install licence file… button

- ① Status: Unlicensed — read-only; every other row shows —.
- ② This machine's code: RL-083A0F2D-AFD578B5-15C76AD2, with Copy beside it - the code a licence is requested for.
- ③ Install licence file…: the button to click.
- ④ Request licence by e-mail: writes the request, with this code, into the panel under the buttons and hands it to your e-mail program.
- ⑤ Close: closes the dialog.


3. **Read the box and click OK.**



Step 3 — the box after the install


- ① Licence installed: ReliaEn Test Fixture Co., Ltd., full edition, expires 2027-09-14.
- ② OK: closes the box. The licence works from this moment.

Part 4 — The result



The licence dialog after the install

- ① Status: Licensed to ReliaEn Test Fixture Co., Ltd. · expires 2027-09-14 - the same sentence as the status line.
- ② Licensee: ReliaEn Test Fixture Co., Ltd.
- ③ Site: Fixture.
- ④ Edition: full.
- ⑤ Features: cmms, reliability, fmea_study, bridge, criticality, asset_health, ai_support, server - the parts of ReliaEn the licence switches on.
- ⑥ Seats: 1.
- ⑦ Issued: 2026-09-15.
- ⑧ Expires: 2027-09-14, the last day the licence is valid.
- ⑨ Licence id: RL-2026-0001.



An analysis after the install: the report's last line

- ① The report's last line: Licensed to ReliaEn Test Fixture Co., Ltd. · RL-2026-0001. The Weibull analysis that was refused before the install now runs, with no restart.
- ② The licence segment: Licensed to ReliaEn Test Fixture Co., Ltd. · expires 2027-09-14.

Part 5 — How to interpret the results

The licence works at once. ReliaEn reads the licence when it starts, after an install and before every analysis, so the file installed here took effect without a restart: the analysis that was refused a minute before now makes its report.

Every report says whose licence made it. The last line of every report page names the licensee and the licence id, and the line goes with the report when it is exported to HTML or Word.

Where the file went. Install licence file… copies the file into your Windows profile, at %LOCALAPPDATA%\ReliaEn\license.rlic, for you only. Keep the file you received: a reinstall on this computer needs it again. A licence for another computer is requested with that computer's code.

What the dates mean. The licence is valid to the end of 2027-09-14. In its last month the status line counts the days left; after that day ReliaEn gives a grace week to install the renewal, and then goes read-only until a renewed file is installed.